


5-TIER SHELVING UNIT

- 175KG CAPACITY/TIER
- BOLTLESS ASSEMBLY
- ADJUSTABLE BEAMS
- · EXPANDABLE SYSTEM

SAFETY INSTRUCTIONS

For your own safety when assembling and using this product, please follow basic safety precautions, including:

- 1. Follow the instructions carefully when assembling.
- 2. Use the tools specified and ensure that appropriate safety gear is worn, such as hard-toed boots.
- 3. Ensure that two people put this product together.
- 4. When the product is assembled, be sure it is stable and firm when standing.
- 5. Do not overload the product, as doing so may cause it to tip over and cause injury.
- 6. Any person using this product should be fully aware of the hazards involved. A responsible adult should always ensure the product is used under supervision or that adequate instruction has been given to children or adults with reduced physical, mental or sensory capabilities, or anyone with a lack of experience using a similar product.
- 7. Return to retailer if defects are found before use.




- 1. Shelves (5 Pieces)
- 2. Shelf Beams Front / Rear (10 Pieces)
- 3. Side Beams (10 Pieces)
- 4. Supports (5 Pieces)
- 5. Plastic Feet (8 Pieces)
- 6. Additional Connectors (4 Pieces)
- 7. Legs (8 Pieces)

Please note: tools required for the construction of this product include a rubber mallet, flathead screwdriver and two-person assembly.


ASSEMBLY INSTRUCTIONS

A. Take four legs (7) and secure four plastic feet (5) to the bottom of each one.




B. Attach four side beams (3) by aligning them with the appropriate eyelets on the legs (7). Use a rubber mallet to secure them into place without damaging the finish of the product. This will leave the user with two end frames. You may need to use a flat headed screwdriver to open the eyelets on the legs to help the beams slot into place.


Please note: if fixing into a five-tier system, leave the top two evelets free.



C. Attach four shelf beams (2) in the same way as the side beams -line up with appropriate eyelets and use a rubber mallet to secure - in order to connect the two end frames together.


F. To allow for a five-tier system to be assembled, place four connectors (6) into the top eyelets situated in the top corners of the current frame. Use these connectors to securely attach the second frame to the top of the first.





D. Attach the support bars (4) by bending the tabs at the end of each one to a 90° angle. Slot these bars into place by sliding them into the correct slots between the front and rear shelf beams (2).

Please note: Two-person assembly is recommended to ensure the product does not topple over and cause injury.




G. Add the shelves (1) by sliding them into place on top of the beams.



H. Once complete, use the remaining plastic feet (5) to cover the top edges of the frame for added safety.

E. For a five-tier system, repeat steps A to D, then continue below.



WARRANTY



Recycling packaging reduces the need for landfill and raw materials. Reuse of recycled material decreases pollution in the environment. Please recycle packaging where facilities exist. Check with your local council authority for recycling advice.

Your warranty form should be retained by you at all times. In order to make a claim under this warranty, you must return the product with your receipt of purchase. Prior to returning your product for warranty, please contact us via our after sales support services.

EMAIL: support@topto.com.au

1 YEAR REPLACEMENT WARRANTY

Your product is guaranteed for a period of 12 months from the original date of purchase and is intended for DIY (Do It Yourself) use only. Our warranty covers labor and parts only. If a product is defective, it will be replaced in accordance with the terms of this warranty. Warranty excludes consumable parts, for example: driver

The following actions will result in the warranty being void:

- 1.If the tool has been operated on a supply voltage other than that specified on the tool.
- 2.If the tool shows signs of damage or defects caused by or resulting from abuse, accidents or alterations.
- 3. Failure to perform maintenance as set out in the instruction manual.
- 4.If the tool is disassembled or tampered with in any way.

How to get 1 extended year warranty?

This product comes with 1 year replacement warranty. However, you may get 1 extra year warranty with conditions(not applicable to batteries and chargers). Please ask for detail by sending an email to support@topto.com.au



CUSTOMER SERVICE &PARTS







