

OWNER'S MANUAL



1000W JUICE BLENDER










SL500

Thank you for buying this **1000W JUICE BLENDER!**
Please read this manual carefully before using the product.

www.stelive.com.au

version 20250408

DESCRIPTION OF SYMBOLS

V	Volts	Hz	Hertz
ac/~	Alternating current	W	Watts
dc/---	Direct current	∅	Diameter
mA	Milliamperes	Ah	Amp hour
	Do not expose to rain.	no	No load speed
/min	Revolutions or reciprocation per minute		
	Electrical Emissions Conformity (EMC)		Transformer Energy Rating (MEPS)
	Warning		Read instruction manual
	Double insulated		Indoor use only

GENERAL SAFETY WARNINGS

IMPORTANT SAFETY INSTRUCTIONS READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

Read this manual thoroughly before first use, even if you are familiar with this type of product. The safety precautions enclosed in here reduce the risk of electric shock and injury when correctly adhered to. Make sure you understand all instructions and warnings.

Keep the user manual in a safe place for future reference, along with the completed warranty information and purchase receipt. If you sell or transfer ownership of this product, pass on these instructions to the new owner.

Always follow basic safety precautions and accident prevention measures when using an electrical appliance. The following statements you will see in this booklet have these meanings:

WARNING: Indicating information concerning your personal safety.

CAUTION: Indicating information on how to avoid damaging the appliance, bench top or cabinetry.

IMPORTANT: Indicating tips and information about use of the appliance.

USAGE CONDITIONS AND RESTRICTIONS

• **Domestic use only:** This appliance is intended for indoor household use only. It is not intended for commercial, industrial or outdoor use. It is not intended for use in a recreational vehicle.

• **Purpose:** Do not use this appliance for anything other than its intended purpose. Other uses are not recommended and may cause fire, electric shock or personal injury.

• **Attachments:** The use of attachments is not recommended by the appliance manufacturer and distributor as they may be hazardous.

• **Improper use:** Damage due to improper use or repairs made by unqualified personnel will void your warranty. We assume no liability for any eventual damages caused by misuse of the product or noncompliance with these instructions.

IMPORTANT: The appliance must be installed using the instructions in this user manual. The manufacturer is not responsible for any damage that might be caused by defective placement, and incorrect installation.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- This appliance is intended for indoor domestic (or household) use only, and is not intended for commercial, trade or industrial use.
- Do not repair or replace any part of the appliance unless specifically recommended in the manual. All other servicing should be done by a qualified technician.

BEFORE USING YOUR APPLIANCE

Prior to using your juice blender, please read all safety and operating instructions thoroughly. Please ensure you follow the steps below before using this product:

- This juice blender must only be installed in accordance with the instructions provided. Incorrect installation may cause harm to persons, damage property and void the product's warranty.
- Unpack the appliance, but keep all packaging materials until you have made sure the new Induction juice blender is undamaged and in good working order. We recommend you keep the original packaging for storing your juice blender when not in use or transporting.

WARNING: Plastic wrapping can be a suffocation hazard for babies and children, so ensure all packaging materials are out of their reach.

WARNING: Do not use the appliance if the rotating sieve or the protecting cover is damaged or has visible cracks.

WARNING: ELECTRICAL HAZARDS

It is important to use your juice blender safely. Follow these instructions carefully to avoid potential electric shock, fire or death.

- In certain circumstances, electrical appliances may be a safety hazard. Check the conformity of voltage and power settings, which are specified on the information plate attached to the appliance and/or packaging, with the usage conditions available.
- Disconnect the appliance from the mains electricity supply before carrying out any work or maintenance on it.
- Alterations to the domestic wiring system must only be made by a qualified electrician.
- A means for disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.
- If the appliance is being hardwired, it must be installed by an authorised technician.
- If the supply cord or plug is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

WARNING: RISK TO CHILDREN

- The appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.
- Children should be supervised to ensure that they do not play with, sit, stand, or climb on the appliance.
- Do not store items of interest to children in cabinets above the appliance. Children climbing on the juice blender could be seriously injured.
- Cleaning and user maintenance shall not be made by children without supervision.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Remove all packaging before using the appliance. Otherwise, serious damage or injury may result.


JUICE BLENDER SAFETY WARNINGS

When using electrical appliance, basic safety precautions should always be used, including the following:

- This appliance is intended to be used in household and similar applications such as: staff kitchen areas in shops, offices and other working environments, farm houses, by clients in hotels, motels and other residential type environments, bed and breakfast type environments.
- Caution! To avoid risk of electric shock, never immerse the cord, plug or power base blender in water or other liquids.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.

- Unplug the appliance when it is not in use. Make sure the appliance is unplugged before assembling, disassembling, adding additional parts, and cleaning.
- Do not pull, twist, or mistreat the power cord.
- Do not allow cord to hang over the side of the counter or table.
- Do not allow cord to touch hot surfaces, including stove.
- Periodically inspect cord and plug for damage. Do not operate any appliance with a damaged cord or plug. If the appliance malfunctions, or is dropped or damaged in any manner, discontinue use. Contact customer service for assistance in obtaining a replacement.
- Avoid contact with moving parts.
- Keep hands and utensils away from the cutting blade while chopping or blending food to reduce the risk of severe personal injury or damage to the device.
- Never allow the motor to run for more time, as it can cause permanent damage to the motor and other parts. If the motor stops working, unplug the Power base and let it cool for twenty minutes before attempting to use it again. Your appliance has an internal thermal breaker that shuts off the unit when it overheats. The Power Base will reset when the unit is unplugged and the thermal breaker cools down.
- To reduce the risk of injury, make sure the blade is securely screwed onto the container before placing it on to Power Base and operating the appliance.
- Never leave the appliance unattended while it is in use.
- Close supervision is necessary when any appliance is used by or near children.
- Do not use the appliance outdoors if exposed to inclement weather elements such as rain or in wet conditions.
- Blades are sharp. Handle carefully.
- Check gasket to make sure it is completely seated in cross blade or flat blade unite before each use.
- The appliance is not intended for use in the microwave. Do not place the cup, containers, Power Base or accessories in the microwave as this may result in damage to the appliance.
- To reduce the risk of personal injury or damaged to the device, keep hands and utensils away from the cutting blade.
- Never blend carbonated beverages. Built-cup pressure from released gases can cause container to burst, resulting in possible injury.
- Do not blend the hot liquids in any of the blending vessels.
- Do not run the appliance when the containers are empty.

1000W JUICE BLENDER




1. Super high cup
2. Blend blade base
3. Power base
4. High cup
5. Cup cover
6. Flat lid
7. Handle lid

SPECIFICATIONS


Model No	SL500
Voltage	220-240V~, 50-60Hz
Rating Wattage	1000W
Continuous Use	Blend≤1min
Insulation	Protection against electric shock: type II

SETUP & PREPARATION

1. Put the machine on a stable table.
2. Firstly add an appropriate amount of purified water in the cup container, then put the vegetables and fruits which have been cut into small pieces in the cup, pay attention that the whole mixed volume can not exceed the maximum scale-line position of the super high cup and the high cup .




3. Screw on the blend blade at the rim of the cup.




OPERATION

4. Invert the cup onto the power base, press and rotate clockwise to ensure that the concave surface on the upper part of the base fits tightly with the convex surface of the cup opening.



5. Plug in the appliance into AC220-240 voltage. At that time, the appliance runs normally. Continuous working time can not exceed 1min.
6. After mixing, please turn off the power switch, then pull the power plug from outlet.
7. Remove the mixing cup counterclockwise from the power base.



8. Open the blade holder, pour out the ingredients, and then you can enjoy the result.



For repeated operations, please follow the above steps.

Note: Do not just mix dry ingredients.

TROUBLESHOOTING

Problem	Solution
The blender is not turning on	Be sure the blade assembly is on the blending cup correctly and locked into place. Plug the blender into an independent and electrical outlet and make sure the blender is securely plugged in. If it still doesn't work, try plugging into a different outlet and/or check your home's circuit breaker.
The blender stops running	The blender has an auto stop feature. After 60 seconds or if blending heavy loads for extended periods the motor overload feature may be activated. To reset, unplug and allow the blender to cool for a minimum of 15 minutes. Reduce the contents of the blending cup and/or clear any jams.
The blade assembly is hard to remove after blending	The ingredients cause pressure, and with the airtight seal, pressure builds up, creating a vacuum or a suction effect. This is normal.

MAINTAINENCE

1. You should always take off the plug when not in use.
2. If the machine is not used for long time, please keep the machine in dry and airiness.
3. You can clean the accessories in water except the motor base.
4. Take off the plug before wipe the motor base, always use the dry cloth to clean, never flush or dip in water.

CARING FOR THE ENVIRONMENT



Power tools that are no longer usable should not be disposed of with household waste, but in an environmentally friendly way. Please recycle where facilities exist. Check with your local council authority for recycling advice.



Recycling packaging reduces the need for landfill and raw materials. Reuse of recycled material decreases pollution in the environment. Please recycle packaging where facilities exist. Check with your local council authority for recycling advice.

WARRANTY POLICY

12-Month Standard Warranty

We are committed to ensuring the quality and reliability of our products. All STELIVE items come with a standard 12-month warranty from the date of purchase, covering defects in materials and workmanship.



What Our Warranty Covers

- Material and manufacturing defects under normal use
- Repair or replacement of defective products at our discretion

Exclusions

- Normal wear and tear
- Damage caused by misuse or unauthorized modifications
- Incidental or consequential damages

How to Claim

To make a warranty claim, please scan the QR code below and complete the online form with your proof of purchase and a description of the issue. We may require the product to be returned for inspection.



Warranty Extension

For added peace of mind, you can extend your warranty by an additional year by joining the STELIVE community (batteries and chargers do not apply).

JOIN US