


**MasterSpec<sup>®</sup>**

# 135W ROTARY TOOL



**MS011**

***Operation and  
maintenance  
instruction manual***

## IMPORTANT! – Safety Instructions for all tools

### WARNING

When using electric power tools, important safety precautions must always be adhered to in order to reduce the risk of fire, electric shock and personal injury.

### PLEASE READ THE FOLLOWING CAREFULLY:

1. **KEEP WORK AREA CLEAN.** Untidy benches and work areas invite injuries.
2. **CONSIDER WORK AREA ENVIRONMENT.** Do not use power tools in damp or wet locations. Do not expose power tools to rain. Keep work areas well lit.
3. **GUARD AGAINST ELECTRIC SHOCK.** Prevent body contact with grounded surfaces. E.g. Radiators, pipes, refrigerator enclosures.
4. **KEEP CHILDREN AWAY.** All visitors must be kept away from the work area. Do not let visitors come into contact with the tool or extension cord.
5. **STORE IDLE TOOLS.** When not in use, tools must be stored in a dry place, out of reach of children.
6. **DO NOT FORCE THE TOOL.** It will do the job in hand better and safer at the rate for which it was intended.
7. **USE THE RIGHT TOOL.** Do not force a small tool to do the job of a heavy-duty power tool. Do not use the tool for the purpose it is not intended for, e.g. Trying to drill through concrete with the 12v mini tool.
8. **DRESS PROPERLY.** Do not wear loose clothing or jewellery, as these can be caught in moving parts. Gloves and non-skid footwear are recommended when working outdoors. Wear protective head cover to contain long hair.
9. **USE SAFETY GLASSES.** Also use face and dust mask to guard against dust.
10. **DO NOT ABUSE THE CORD.** Never carry the tool by the cord or pull the cord to disconnect the tool. Keep the cord away from heat, oil or sharp objects.
11. **SECURE YOUR WORK.** Use clamps or a vice to hold your work in position. It is much safer than using your hand and it frees both hands to operate the tool.
12. **DO NOT OVERREACH.** Keep proper footing and balance at all times.
13. **MAINTAIN TOOLS WITH CARE.** Keep tools clean for better and safer performance. Follow instructions for lubricating and changing accessories. Keep hands dry, clean and free from oil and grease.
14. **DISCONNECT TOOLS.** When not in use, before servicing and when changing any accessories.
15. **REMOVE ADJUSTING KEYS AND WRENCHES.** Have the habit to check and see that keys and adjusting wrenches are removed from the tool before turning on.

16. **AVOID UNINTENTIONAL STARTING.** Do not carry plugged-in tool with finger on switch. Be sure that the switch is off when plugging in.

17. **OUTDOOR EXTENSION CORDS.** When the tool is used outdoors, only use extension cords intended for use outdoors and so marked.

18. **STAY ALERT.** Watch what you are doing. Use common sense. Do not operate the tool when you are tired.

19. **CHECK DAMAGED PARTS.** Before using the tool, a guard or other part that is damaged, these must be carefully checked to ensure that the tool will perform properly the intended function. Check for alignment of moving parts, binding of moving parts, breakage of parts, mounting and any other condition that may affect the tool's operation.

20. **DO NOT OPERATE** portable electric tools near flammable liquids or in gaseous or explosive atmospheres. Motors in these tools normally spark, and the sparks may ignite fumes.

### SPECIFICATIONS

Available Voltages	220-240V~50HZ
Maximum Output	135 Watt
No Load Speed	10000-32000 rpm
Collet Chuck Capacity	Max Ø3.2mm dia.

### MULTIFUNCTION POWER TOOL USE

This rotary tool can be used for drilling, grinding, sanding and polishing, as well as engraving, cutting and removing rust in tight spaces or inaccessible places. The tool can be used on most metals, glass, wood and ceramics. For best performance and results keep the speed as even as possible without exercising too much pressure. As a guideline, use the tool at low speed for all large accessories, such as polishing for example, and at high speed for smaller accessories such as those used for engraving. For grinding and engraving, hold the tool as if it were a pen.

### MULTIFUNCTION POWER TOOL START-UP

Never start up or stop the tool is the accessory is in contact with the piece to be worked on. Hold it firmly and press the ON/OFF switch. The tool will run continuously until the switch is turned to OFF position. The speed can be adjusted while the tool is running.

### PLACING ACCESSORIES INTO THE TOOL

Always switch the tool off first. Hold the locking button at the front of the tool down and undo the collet chuck (anti-clockwise). Insert the collet that matches the shaft size of the accessory to be used. Place the collet nut over the collet and then insert the accessory shaft into the collet chuck ensuring maximum shaft contact. Then tighten up the collet nut. (DO NOT USE PLIERS).

## USEFUL HINTS & TIPS

1. Your rotary tool will become warm after prolonged use and so must be switched off and allowed to cool down.
2. To ensure smooth running, the spindle should be oiled periodically.
3. Do not apply too much radial pressure to the accessory bits while polishing, cleaning, sanding or grinding. By doing this, you will put a strain on the spindle and adversely affect the precision of the tool.
4. Always work with a sensitive touch so as not to impede the efficiency of your mini tool.
5. When drilling metal, always mark the drilling point with a centre punch first, so that your rotary tool does not slip.
6. Always ensure that you have maximum contact between the accessory shaft and the collet chuck.
7. Vary the speed of the tool for the work in hand, eg. Low speed for polishing & cleaning and high speed for engraving.
6. Do not leave your tool unattended while switched on.
7. Do not use or store your tool in damp or wet conditions.

## IMPORTANT GENERAL SAFETY TIPS!

1. The Tool should be unplugged when changing accessories.
2. If you stall the tool, switch it off immediately.
3. Periodically check the tightness of your collet chuck, especially during prolonged use of the same accessory.
4. After use, always disconnect your power tool.
5. Do not undertake repair of the power tool your self.
6. Do not leave your tool unattended while switched on.
7. Do not use or store your tool in damp or wet conditions.

## FLEXYDRIVE ASSEMBLY

Remove the front ring nut from the tool by turning in an anti-clockwise direction. Partially unscrew the blocking ring nut from the spindle. Partially extract the internal transmission cable from the flexydrive. Insert the flexydrive transmission cable into the spindle of the tool pushing it in as far as possible. Keep the spindle block button pressed in and screw the spindle blocking ring nut turning it in a clockwise direction. Tighten using the spanner for this purpose. Screw the threaded end of the flexydrive onto the body of the tool and tighten, screwing in a clockwise direction.

## SPEED ADJUSTMENT


The multifunction power tool is equipped with speed control. Do not change the speed while the tool is working. The speed switch is located on the rear of the tool. Turn it to increase or reduce speed. Use the tool at low speed for polishing and similar operations, but use higher speed for drilling or cutting action.

## MAINTENANCE

### ⚠ WARNING

**Do not use solvents to clean the tool.**  
**Inspect the chuck and remove any dirt or debris.**

Maintain the rotary tool by adopting a program of conscientious repair and maintenance in accordance with the following recommended procedures. It is recommended that the general condition of any tool be examined before it is used. Keep your tool in good repair. Keep handles dry, clean, and free from oil and grease. The following chart is based on a normal operation schedule.

Maintenance Interval	Maintenance Point
Before each use	<p>Inspect the general condition of the rotary tool. Check for:</p> <ol style="list-style-type: none"><li>1. loose hardware,</li><li>2. misalignment or binding of moving parts,</li><li>3. damaged cord/electrical wiring,</li><li>4. cracked or broken parts, and</li><li>5. any other condition that may affect its safe operation.</li></ol>
After use	<p>Wipe external surfaces of the rotary tool with a clean cloth.</p>
When the carbon brushes wear out	<p>When the carbon brushes wear out, the rotary tool will spark and/or stop. Discontinue use as soon as this happens. They should be replaced prior to re-using the tool. Carbon brushes are a wearing component of the tool and therefore not covered under warranty. Continuing to use the rotary tool when carbon brushes need to be replaced may cause permanent damage to the tool.</p> <p>Carbon brushes will wear out after many uses but when the carbon brushes need to be replaced, take the tool to an electrician or a service technician for a quick and low cost replacement.</p> <p>Always replace both carbon brushes at the same time.</p> 

**MasterSpec**

**CUSTOMER SERVICE  
&PARTS**

Contact: [support@topto.com.au](mailto:support@topto.com.au)